

Thank you for purchasing our FRENIC-MEGA series of inverters.  
The purpose of this instruction manual is to provide handling information in handling, setting up and operating of the FRENIC-MEGA series of inverters.  
Do not use this product until you have full knowledge of the product, safety information and instructions from Instruction Manual (Detailed Version) and Related documents.

[Related Documents]  
Instruction Manual (Detailed Version) INR-SI47-2392b-E  
User's Manual 2447-E-0162  
RS-485 Communication User's Manual 2447-E-0082  
This manuals can be downloaded in PDF form from QR code in right figure.

Fuji Electric Co., Ltd.

Please feel free to send your comments regarding any errors or omissions you may have found, or any suggestions you may have for generally improving the manual. In no event will Fuji Electric Co., Ltd. be liable for any direct or indirect damages resulting from the application of the information in this manual.

**CAUTION**

Thank you for purchasing our FRENIC-MEGA series of inverters.

- This product is designed to drive a three-phase induction motor and three-phase permanent magnet synchronous motor. Read through this instruction manual and be familiar with the handling procedure for correct use.
- Improper handling might result in incorrect operation, a short life, or even a failure of this product as well as the motor.
- Deliver this manual to the end user of this product.
- Keep this manual in a safe place until this product is discarded.
- For instructions on how to use optional components, refer to the instruction and installation manuals for that optional device.
- Drawings in this manual may be illustrated without covers or safety shields for explanation of detail parts. Restore the covers and shields in the original state and observe the description in the manual before starting operation.

**WARNING**

**Application**

- The FRENIC-MEGA is a piece of equipment used to run three-phase motors. It cannot be used for single-phase motors or other applications.
- Failure to observe this could result in fire or an accident.**
- The FRENIC-MEGA cannot be used as is for applications which may have a direct effect on the human body such as life support machines.
- Strict quality control has been observed in the manufacture of this product, however, safety devices should be installed when the product is used for equipment which may result in a serious accident or loss of life.
- Failure to observe this could result in an accident or injury.**

**Installation**

- Install on noncombustibles such as metal.
- Do not install near combustibles.
- Failure to observe this could result in fire.**
- If using an optional DC reactor, there is a possibility of users coming into contact with main circuit terminal block parts (live parts). In such cases, take measures such as installing the product in a location where it will not easily come into contact with people.
- Failure to observe this could result in electric shock or injury.**

**Wiring**

- If no zero-phase current (earth leakage current) detection device such as a ground-fault relay is installed in the upstream power supply line in order to avoid the entire power supply system's shutdown unnecessary to factory operation, install a residual-current-operated protective device (RCD) / earth leakage circuit breaker (ELCB) individually to inverters to break the individual inverter power supply lines only.
- Connect to the power supply via a molded case circuit breaker or earth leakage circuit breaker (with overcurrent protection function) for each inverter. Use the recommended molded case circuit breaker or earth leakage circuit breaker, and do not use devices that exceed the recommended capacity.
- Be sure to use the specified wire size.
- Tighten terminals with the prescribed tightening torque.
- If there are multiple inverter and motor combinations, do not use multi-core cables for the purpose of bundling and wiring for multiple combinations.
- Do not install a surge suppressor to the inverter output side (secondary side).
- Be sure to connect an optional DC reactor (DCR) when the capacity of the power supply transformer exceeds 500 kVA, and is at least 10 times the inverter rated capacity.
- Failure to observe this could result in fire.**
- Ground the inverter in compliance with the national or local electric code.
- Be sure to ground the inverter ground terminal (ⓄG) grounding wire.
- Failure to observe this could result in electric shock or fire.**
- Wiring work should be carried out by qualified professionals.
- Carry out wiring work after ensuring that the power has been turned OFF.
- Failure to observe this could result in fire or an accident.**
- Always carry out wiring after installing the unit.
- Failure to observe this could result in electric shock or injury.**
- Ensure that the number and phase of the product input power supply matches that for the connected power supply.
- Do not connect the power lines to the inverter output terminals (U, V, W).
- When connecting a DC braking resistor (DBR), never connect it to terminals other than terminals P(+) and DB.
- Control signal lines generally do not have a reinforced insulation coating, and therefore if control signal lines come into contact with live parts of the main circuit, the insulation coating may be damaged for some reason. In such a case, there is a danger that high voltage from the main circuit will be applied to the control signal lines, and therefore care should be taken so that they do not come into contact with live parts of the main circuit.
- Failure to observe this could result in an accident or electric shock.**
- Switch all switches after first waiting for at least 5 minutes for FRN0115G2S-2G / FRN0060G2□-4G or lower inverters, or 10 minutes for FRN0146G2S-2G / FRN0075G2□-4G or higher inverters after the LED monitor and charge lamp are off, and using a device such as a tester to ensure that the DC intermediate circuit voltage across main circuit terminals P and N has dropped to a safe level (<25 VDC or less).
- Failure to observe this could result in electric shock.**

**Operation**

- Be sure to attach the inverter surface before turning the power ON. Do not remove the surface cover while the power is ON.
- Do not operate the unit with wet hands.
- Failure to observe this could result in electric shock.**
- Set function codes after understanding of this instruction manual. If operation is performed after recklessly changing function code data, the motor will rotate at a motor and speed at which the machine is unable to tolerate.
- When auto tuning is started, the motor rotates. Conduct a sufficient check to ensure that there is no danger even when the motor rotates.
- Failure to observe this could result in an accident or injury.**
- Even if the inverter cuts off the supply of power to the motor, if voltage is being applied to main power supply input terminals L1/R, L2/S, and L3/T, voltage may be applied to inverter output terminals U, V and W.
- Even if the motor is stopped by DC braking operation or pre-acceleration operation, voltage will be applied to the inverter output U, V and W terminals.
- Failure to observe this could result in electric shock.**
- Inverter high-speed operation settings can be specified easily. If settings are changed, use the product after sufficiently checking the motor and machine specification.
- Failure to observe this could result in an accident or injury.**

**Maintenance and inspection, part replacement**

- Carry out inspection after waiting at least 5 minutes for FRN0115G2S-2G / FRN0060G2□-4G or lower inverters, or 10 minutes for FRN0146G2S-2G / FRN0075G2□-4G or higher inverters after the LED monitor and charge lamp are OFF, and use a device such as a tester to ensure that the DC intermediate circuit voltage across main circuit terminals P(+) and N(-) has dropped to a safe level (<25 VDC or less).
- Failure to observe this could result in electric shock or injury.**
- Be sure to perform the daily inspection and periodic inspection described in the instruction manual. Lengthy use of the product without inspection could result in inverter failure, damage, or accident and fire.
- A periodic inspection cycle of 1 to 2 years is recommended, however, the cycle may be shortened depending on the usage conditions.
- It is recommended that parts for periodic replacement be replaced after the standard number of years indicated in the instruction manual. Lengthy use of the product without replacing parts could result in inverter failure, damage, or accident and fire.
- Contact outputs [30A/B/C] and [YSA/C] use relays, and may remain ON or OFF, or in an indefinite state when the life is reached. In the interests of safety, equip the product with an external protection function.
- Failure to observe this could result in fire or an accident.**
- Maintenance and inspection, and part replacement should only be carried out by the authorized personnel.
- Remove all metal objects (watches, rings, etc.) before beginning work.
- Be sure to use insulated tools.
- Never modify the product.
- Failure to observe this could result in electric shock or injury.**

**CAUTION**

**Installation**

- Do not hold the surface cover when transporting the product.
- Failure to observe this could result in injury if the product is dropped.**
- Take measures to prevent foreign materials such as dust, water vapor, wood shavings, dust, or metal scraps getting into the inverter, or adhering to the cooling fan.
- Use the specified screws for changing the mounting base.
- Failure to observe this could result in fire or an accident.**
- Do not install or connect with conductors with external terminal parts.
- Failure to observe this could result in fire, an accident, or injury.**

**Wiring**

- The inverter, motor and wiring generate electric noise, which may cause nearby sensors and devices to malfunction. Employ noise countermeasures to prevent malfunction.
- Failure to observe this could result in an accident.**

**Operation**


- The cooling fans and braking resistors become very hot. Do not touch.
- Failure to observe this could result in burns.**
- Mechanical holding is not possible with the inverter brake function.
- Failure to observe this could result in an accident.**
- The digital input terminals are equipped with a function used to start and stop operation or change the speed command with the "FWD" operation command or "BX" free-run command and the digital input terminals. operation may start suddenly, or the speed may change significantly simply by changing the function code settings. Make changes to function code settings after sufficiently ensuring safety.
- With digital input functions ("SS1", "SS2", "SS4", "SS8", "H2Hz1", "H2PID", "TVS", "LE", etc.) used to change the operation procedure for operation commands or command procedure for speed commands can be assigned. Depending on the conditions, changes to these signals may result in operation being started suddenly or the speed changing suddenly.
- Ensure safety before modifying customizable logic related function code settings (U codes and related function codes) or turning ON the "Cancel automatically logic" terminal command C.L.C. Depending upon the settings, such modification or cancellation of the customizable logic may change the operation sequence to cause a sudden motor start or an unexpected motor operation. Carry out a sufficient safety check beforehand.
- Failure to observe this could result in an accident or injury.**

**Disposal**

- If disposing of the FRENIC-MEGA, handle as industrial waste.
- Failure to observe this could result in injury.**

Chapter 1 BEFORE USE

**1.1 Acceptance Inspection (Nameplate and Inverter Type)**  
Unpack the package and check the following:  
(1) Ensure that the package contains both the inverter unit and instruction manual (this manual), and that the product has suffered no damage (breakage, dents, parts that have fallen off) during transport.  
(2) The (a) Main Nameplate and (b) Sub Nameplate shown in Figure 1-1 are affixed to the inverter. Ensure that the product is the same as the one ordered.



TYPE: Type of inverter

Code	Series name	Code	Destination/Manual
FRN	FRENIC series	G	Global/English

Code	Input power source	Code	Enclosure
2	3-phase 200V	S	Standard (basic type)(P20/P30)
4	3-phase 400V	E	EMC filter built-in type

Code	Order of development	Code	Applicable range
2	2	G	High performance, multifunctional type

3-phase 200 V series

Code	Applicable motor rating	Code	Applicable motor rating
FRND kW (HP)	FRND kW (HP)	FRND kW (HP)	FRND kW (HP)
0003	0.4 (1/2)	0002	0.4 (1/2)
0005	0.75 (1)	0003	0.75 (1)
0018	3.7 (5)	0009	3.7 (5)
0032	5.5 (7.5)	0018	5.5 (7.5)
0059	11 (15)	0031	11 (15)
0346	75 (100)	0432	90 (125)
0432	90 (125)	0432	110 (150)

3-phase 400 V series

Code	Applicable motor rating	Code	Applicable motor rating
FRND kW (HP)	FRND kW (HP)	FRND kW (HP)	FRND kW (HP)
0002	0.4 (1/2)	0002	0.4 (1/2)
0003	0.75 (1)	0003	0.75 (1)
0009	3.7 (5)	0009	3.7 (5)
0018	5.5 (7.5)	0018	5.5 (7.5)
0031	11 (15)	0031	11 (15)
1170	500 (800)	1170	500 (800)
1386	630 (900)	1386	710 (1000)

SEIR No.: Product number: T31A 1 2 3 A 0 5 7 9 E AA

Production year and week: 3 0 1

Production week: This indicates the week number that is numbered from 1st week of January.

Production year: Last digit of year

Product version

If you suspect the product is not working properly or if you have any questions about your product, contact your Fuji Electric representative.

Chapter 2 INSTALLATION AND WIRING

**2.1 Operating Environment**  
Install the inverter in an environment that satisfies the requirements listed in Table 2-1.

Item	Indoors	Environmental conditions: IEC60721-3-3/C22	Specifications
Ambient temperature	-10 to +55 °C (14 to 131°F) (Current derating is necessary in a 10 to +55 °C (122 to 131°F) range.) When installed closely side-by-side (FRN0115G2S-2G / FRN0060G2□-4G or lower): -10 to +40 °C (14 to 104°F)		
Relative humidity	5 to 95% RH (there should be no condensation)		
Atmosphere	The inverter must not be exposed to dust, direct sunlight, corrosive gases, flammable gases, oil mist, vapor or water droplets. The atmosphere can contain a small amount of salt (0.1 mg/m <sup>3</sup> or less per year). The inverter must not be subjected to sudden changes in temperature that will cause condensation to form.		
Altitude	1,000 m (3,300 ft) max. (Note 2)		
Atmospheric pressure	86 to 106 kPa		
Vibration	Type of inverter	2 to less than 5 Hz	9 to less than 20 Hz
	FRN0115G2S-2G or lower, FRN0060G2□-4G or lower (max. amplitude)	3 mm	9.8 m/s <sup>2</sup>
	FRN0288G2S-2G or lower, FRN0180G2□-4G or lower		2 m/s <sup>2</sup>
	FRN0146G2S-2G or higher, FRN0075G2□-4G or higher		1 m/s <sup>2</sup>

(Note 1) Do not install the inverter in an environment where it may be exposed to lint, cotton waste or moist dust or dirt which will clog the heat sink of the inverter. If the inverter is to be used in such an environment, install it in a cabinet to prevent lint, etc. getting in.

(Note 2) If you use the inverter in an altitude above 1,000 m (3,300 ft), you should apply an output current derating factor as listed in Table 2-2

Altitude	Output current derating factor
1,000 m (3,300 ft) or less	1.00
1,000 to 1,500 m (3,300 to 4,900 ft)	0.97
1,500 to 2,000 m (4,900 to 6,500 ft)	0.95
2,000 to 2,500 m (6,500 to 8,200 ft)	0.91
2,500 to 3,000 m (8,200 to 9,800 ft)	0.88


Fuji Electric strongly recommends installing inverters in a panel for safety reasons, in particular, when installing the ones whose enclosure rating is IP00. When installing the inverter in a place out of the specified environmental requirements, it is necessary to derate the inverter or consider the panel engineering design suitable for the special environment or the panel installation location.

**2.2 Installation**  
**2.2.1 Installation Surface**  
Please install the inverter on noncombustibles such as metal. Also, do not mount it upside down or horizontally.

**2.2.2 Surrounding Space**  
Secure the surrounding space shown in Figure 2-1 and Table 2-3. If enclosing the product in a cabinet and so on, be sure to provide adequate ventilation to the cabinet, as the ambient temperature may rise. Do not contain it in small enclosures with low heat dissipation capacity.

**■ Installation of Multiple Inverters**  
If installing two or more units inside the same equipment or cabinet, they must be installed side by side as a rule. If vertical installation is unavoidable, install partitions to prevent heat dissipation from inverters below affecting those above. With FRN0115G2S-2G / FRN0060G2□-4G or lower inverters, only in the case of an ambient temperature of 40°C (104°F) or below is it possible to install inverters and converters closely together horizontally.

Type of inverter	A	B	C
FRN□□□□G2□-□G	□	□	□
G2S-2G	G2□-4G	□	□
0003 to 0008	0002 to 0004	50 (1.97)	0 (0)
0011 to 0115	0006 to 0060	10 (0.39)	100 (3.9)
0146 to 0432	0075 to 0250	—	100 (3.9)
0432 to 0592	0050 to 1386	50 (1.97)	150 (5.9)
0432 to 0592	0050 to 1386	150 (5.9)	150 (5.9)




**■ Installation with External Cooling**  
The external cooling installation reduces the generated heat inside the panel by dissipating approximately 70% of the total heat generated (total heat loss) by mounting the cooling fins protruding outside the equipment or cabinet. The external cooling unit body has a protective construction of IP65. Installation with external cooling is possible for inverters FRN0115G2S-2G / FRN0060G2□-4G or lower with the addition of an external cooling attachment (option), and for FRN0146G2S-2G / FRN0075G2□-4G or higher inverters by moving the mounting base. (For external cooling attachment (option) external drawings, refer to Chapter 11 section 11.16 in the User's Manual, and for details on the installation method for FRN0146G2S-2G / FRN0075G2□-4G inverters, refer to Chapter 2 section 2.1 in the same manual.)  
Take measures to prevent foreign material such as lint, wastewater, wood shavings, dust, or metal scraps getting into the inverter, or adhering to the cooling fan.

**2.2.3 Removal and Attachment of the Front Cover and the Wiring Guide**  
Carry out wiring work in the following order (The descriptions assume that the inverter has already been installed). If using the RS-485 communication cable for such purposes as remotely operating the keypad, always remove the RS-485 communication cable from the RJ-45 connector before removing the front cover.  
(1) FRN0115G2S-2G / FRN0060G2□-4G or lower inverters  
1) Loosen the screws of the front cover. Hold both sides of the front cover with the hands, slide the cover downward, and pull. Then remove it to the upward direction.  
2) Push the wiring guide upward and pull. Let the wiring guide slide up and remove it.  
3) After routing the wires, attach the wiring guide and the front cover reversing the steps above.



(2) FRN0146G2S-2G / FRN0075G2□-4G or higher inverters  
1) Loosen the screws of the front cover. Hold both sides of the front cover by hand, and slide the cover upward to remove.  
2) After carrying out wiring work, align the top of the front cover with the hole on the cover, and reattach using the opposite procedure to that in Figure 2-4. Open the keypad case to expose the control PCB.



**2.2.4 Terminal Layout and Screw Specifications**  
**2.2.4.1 Screw Specifications and Recommended Wire Size (Main Circuit Terminals)**  
The specifications for the screws used in the main circuit wiring and the wire sizes are shown below. Exercise caution as the terminal position varies depending on inverter capacity. The two ground terminals (ⓄG) are not differentiated for the input side (primary side) and the output side (secondary side). Also, use crimped terminals with insulating sleeves compatible for main circuit or terminals with insulating tubes. The recommended wire sizes are shown depending on cabinet temperature and wire type.

Inverter type	Main circuit		Grounding		Control power auxiliary input	
	Screw size (driver size)	Tightening torque N·m (ft·lb)	Screw size (driver size)	Tightening torque N·m (ft·lb)	Screw size (ft·lb)	Tightening torque N·m (ft·lb)
Three-phase 200 V						
FRN003G2S-2G	FRN003G2□-4G	M3.5	1.7 (1.9)	M3.5	1.7 (1.9)	—
FRN0008G2S-2G	FRN0008G2□-4G	M4	1.8 (1.9)	M4	1.8 (1.9)	—
FRN0011G2S-2G	FRN0011G2□-4G	M4	1.8 (1.9)	M4	1.8 (1.9)	—
FRN0018G2S-2G	FRN0018G2□-4G	M5	3.5 (31.0)	M5	3.5 (31.0)	—
FRN0032G2S-2G	FRN0032G2□-4G	M5	3.5 (31.0)	M5	3.5 (31.0)	—
FRN0059G2S-2G	FRN0059G2□-4G	M6 (No.3)	5.8 (51.3)	M6 (No.3)	5.8 (51.3)	—
FRN0075G2S-2G	FRN0075G2□-4G	M6 (No.3)	5.8 (51.3)	M6 (No.3)	5.8 (51.3)	—
FRN0146G2S-2G	FRN0146G2□-4G	M8	13.5 (119)	M8	13.5 (119)	—
FRN0180G2S-2G	FRN0180G2□-4G	M10	27 (239)	M8	13.5 (119)	1.2 (10.6)
FRN0288G2S-2G	FRN0288G2□-4G	M10	27 (239)	M10	27 (239)	—
FRN0346G2S-2G	FRN0346G2□-4G	M12	48 (425)	M10	27 (239)	—
FRN0432G2S-2G	FRN0432G2□-4G	M12	48 (425)	M10	27 (239)	—

**2.2.4.2 Terminal Layout Diagrams (Main Circuit Terminals)**  
Refer to Chapter 2 section 2.2.5 [2] in the User's Manual for the main circuit terminal layout.  
The terminals will have high voltage when power is ON. Failure to observe this could result in electric shock.  
Main circuit: L1/R, L2/S, L3/T, P1(+), N(-), DB, U, V, W, R, D, AUX-contact (30A, 30C, 30D, YSA, YSC)  
Insulation level: Main circuit - casing: Basic insulation (overvoltage category II, pollution degree 2)  
Main circuit - control circuit: Reinforced insulation (overvoltage category II, pollution degree 2)  
Contact output - control circuit: Reinforced insulation (overvoltage category II, pollution degree 2)

**2.2.5 Recommended Wire Size**  
Table 2-5 shows recommended wire sizes. The examples of recommended wire sizes for main circuit terminals are based on the use of single HV wires at ambient temperature of 50°C (122°F).  
Refer to Chapter 2 in the User's Manual for conditions other than these.

Power system	Standard input voltage (kVAC)	Inverter type (Note 1)	Recommended wire size (mm <sup>2</sup> )							
			Main power supply input [L1/R, L2/S, L3/T]		For DC reactor [P1(+), P1(-)]		For braking resistor connection [P(+), DB]			
Three-phase 200 V	3.3	0.4	2.0	2.0	2.0	2.0	2.0	2.0		
		0.75	2.0	2.0	2.0	2.0	2.0	2.0		
		1.5	2.0	2.0	2.0	2.0	2.0	2.0		
		2.2	2.0	2.0	2.0	2.0	2.0	2.0		
		3.7	2.0	2.0	2.0	2.0	2.0	2.0		
		5.5	2.0	3.5	3.5	2.0	2.0	3.5		
		7.5	2.0	5.5	5.5	2.0	2.0	5.5		
		11	2.0	5.5	14	8.0	2.0	2.0	8.0	
		15	FRN0115G2S-2G	FRN0115G2□-4G	14	14	14.0	2.0	8.3	14
		18.5	FRN0180G2S-2G	FRN0180G2□-4G	14	22	22.0	2.0	2.0	14
		22	FRN0288G2S-2G	FRN0288G2□-4G	22	38	38.1	2.0	2.0	14
		30	FRN0346G2S-2G	FRN0346G2□-4G	38	60	60.2	2.0	2.0	14
37	FRN0432G2S-2G	FRN0432G2□-4G	38	60	38	2	—	14		
45	FRN0592G2S-2G	FRN0592G2□-4G	60	100	60	—	2	22		
55	FRN0752G2S-2G	FRN0752G2□-4G	100	100	100	5.5	3.5	22		
75	FRN0902G2S-2G	FRN0902G2□-4G	150	150	150	—	5.5	22		
90	FRN1170G2S-2G	FRN1170G2□-4G	150	—	150	8	—	22		
110	FRN1386G2S-2G	FRN1386G2□-4G	200	250	200	14	—	22		
110	—	FRN0432G2S-2G	200	250	—	14	38	—		
Three-phase 400 V	3.3	0.4	2.0	2.0	2.0	2.0	2.0	2.0		
		0.75	2.0	2.0	2.0	2.0	2.0	2.0		
		1.5	2.0	2.0	2.0	2.0	2.0	2.0		
		2.2	2.0	2.0	2.0					

Characteristic	Terminal symbol	Terminal command	Function description
Analog input	[V2]	Analog setting voltage input (V2 function)	(1) Frequency is set up according to the external analog voltage input command value. <ul style="list-style-type: none"> <li>±10 to ±10 VDC (0 to ±100%) (normal operation)</li> <li>±10 to ±10 VDC (0 to ±100%) (inverse operation)</li> </ul> (2) Other than frequency settings, this terminal can be assigned to PID commands, PID control feedback signals, and other functions. In this case, the terminal voltage settings, torque limit values, torque command values / torque current command values, speed limit values, and analog input motors with analog input. (3) Hardware specifications <ul style="list-style-type: none"> <li>Input impedance: 22 kΩ</li> <li>Up to ±15 VDC can be input. However, input exceeding ±10 VDC will be recognized as ±10 VDC.</li> </ul> (4) Digital input terminals [X0] and [X1] can be set up as a pulse train input terminal by changing the function code. <ul style="list-style-type: none"> <li>Maximum input pulse: 30 kHz</li> <li>When connected to open collector output pulse generator (A pull-up resistor and pull-down resistor are required.)</li> <li>100 kHz: When connected to complementary output pulse generator</li> </ul> Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details on function code settings.
	[PTC]	PTC / NTC thermistor input (PTC / NTC function)	The terminal is insulated from terminals [CM]. [CMY].
Digital input	[I1]	Analog common	The terminal is the common terminal for analog input signals (terminals [I3], [I2], [I1], [I2], [FM1], and [FM2]). The terminal is insulated from terminals [CM]. [CMY].
	[X1]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X2]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X3]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X4]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X5]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X6]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X7]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X8]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
	[X9]	Digital input 1 to 9	(1) Various signals (coast to stop command, external alarm, multi-speed selection, etc.) can be set with function codes E01 to E09. E98, E99. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The input mode and SINK / SOURCE can be switched using SW1. (3) The operating mode between digital input terminal and terminal [CM] can be switched to "ON when shorted (active ON)" or "OFF when shorted (active OFF)".
Digital input	[FWD]	Forward rotation run/stop command input	Refer to the User's Manual, Chapter 2 section "2.2.6 Control circuit terminals" for details on digital input circuit specifications.
	[REV]	Reverse rotation run / stop command input	Refer to the User's Manual, Chapter 2 section "2.2.6 Control circuit terminals" for details on digital input circuit specifications.
Digital input	[EN1]	Enable input	(1) When terminals [EN1]-[PLC] or terminals [EN2]-[PLC] are OFF, the inverter output transistors stop switching (safe torque off, STO). Be sure to operate terminals [EN1] and [EN2] simultaneously; otherwise an $\overline{C}$ F alarm is issued and the operation of the inverter will be disabled. (2) The input mode for terminals [EN1] and [EN2] is fixed to source. The mode cannot be switched to sink. (3) This function can be enabled and disabled with SW7. If using this function, set the respective SW7 switches to the OFF side. Refer to the User's Manual, Chapter 2 section "2.2.6 Control circuit terminals" for details on terminal [EN1] and [EN2] circuit specifications.
	[EN2]	Enable input	(1) When terminals [EN1]-[PLC] or terminals [EN2]-[PLC] are OFF, the inverter output transistors stop switching (safe torque off, STO). Be sure to operate terminals [EN1] and [EN2] simultaneously; otherwise an $\overline{C}$ F alarm is issued and the operation of the inverter will be disabled. (2) The input mode for terminals [EN1] and [EN2] is fixed to source. The mode cannot be switched to sink. (3) This function can be enabled and disabled with SW7. If using this function, set the respective SW7 switches to the OFF side. Refer to the User's Manual, Chapter 2 section "2.2.6 Control circuit terminals" for details on terminal [EN1] and [EN2] circuit specifications.
Digital input	[PLC]	Programmable controller signal power supply	(1) Connect the output signal supply for the programmable controller. (Rated voltage: +24 VDC (power supply voltage fluctuation range: 20 to +2 VDC), maximum 100 mA) (2) The terminal can also be used as the power supply for loads connected to transistor outputs. Refer to the "Transistor output" section for details. Gain adjustable range: 0 to 300%.
	[CM]	Digital common	This is a common terminal for digital input signals. The terminal is insulated from terminals [I1]. [CMY].
Analog output	[FM1]	Analog monitor (FMA function)	These terminals output analog DC voltage of 0 to ±10 VDC, and analog DC voltage current of 0 to 20 mA DC or 0 to 20 mA DC monitor signals. The [FM1] output form (VO1 / IO1) can be switched using SW6 on the PCB and function code F29. The signal current is selected from the following by setting function code F31 data. The [FM2] output form (VO2 / IO2) can be switched using SW6 on the PCB and function code F32. The signal current is selected from the following by setting function code F61 data. * Allowable impedance for connection: Min. 5 kΩ (with output of 0 to ±10 VDC) (up to two analog voltmeters (0 to 10 VDC, input impedance 10 kΩ) can be connected.) * Allowable impedance for connection: Max. 500 Ω (with output of 4 to 20 mA DC)
	[FM2]	Analog monitor (FMA function)	These terminals output analog DC voltage of 0 to ±10 VDC, and analog DC voltage current of 0 to 20 mA DC or 0 to 20 mA DC monitor signals. The [FM1] output form (VO1 / IO1) can be switched using SW6 on the PCB and function code F29. The signal current is selected from the following by setting function code F31 data. The [FM2] output form (VO2 / IO2) can be switched using SW6 on the PCB and function code F32. The signal current is selected from the following by setting function code F61 data. * Allowable impedance for connection: Min. 5 kΩ (with output of 0 to ±10 VDC) (up to two analog voltmeters (0 to 10 VDC, input impedance 10 kΩ) can be connected.) * Allowable impedance for connection: Max. 500 Ω (with output of 4 to 20 mA DC)
Analog output	[I1]	Analog common	This is a common terminal for analog input / output signals. The terminal is insulated from terminals [CM]. [CMY].
	[FMP]	Pulse monitor (FMP function)	This terminal outputs a pulse signal. The signal current is selected in the same way as that as for the FM1 / 2 function by setting function code F35 data. * Allowable impedance for connection: Min. 5 kΩ (up to two analog voltmeters (0 to 10 VDC, input impedance 10 kΩ) can be connected.) * Pulse rate: Approx. 50%; pulse rate: 25 to 6000 ps (at full scale) * (Set F34 to between 1 and 300% if using as average voltage output.) * Pulse delay: Approx. 50%; pulse rate: 25 to 6000 ps (at full scale)
Digital output	[CM]	Digital common	This is a common terminal for digital input signals and terminal [FMP]. The terminal is insulated from terminals [I1]. [CMY]. This is the same terminal as terminal [CM] for digital input.
	[Y1]	Transistor output 1 to 4	(1) Various signals (running signal, frequency reached signal, overload forecast signal, etc.) set up by function code E20 to E24 can be output. Refer to the User's Manual, Chapter 5 "FUNCTION CODES" for details. (2) The operating mode between transistor output terminal [Y1] to [Y4] and terminal [CM] can be switched to "ON when signal output (active ON)" or "OFF when signal output (active OFF)". * Maximum voltage for pull-up power supply: 48 V, maximum load current when ON: 50 mA
Transistor output	[CMY]	Transistor output common	This is a common terminal for transistor output signals. The terminal is insulated from terminals [CM]. [I1].
	[Y5A]	General-purpose relay output	(1) The same signals as those of terminals [Y1] to [Y4] can be selected and output as multi-purpose relay outputs. Contact capacity: 250 VAC 0.3 A cosp = 0.3, 48 VDC 0.5 A (2) It is possible to switch between a "short circuit between terminals [Y5A] to [Y5C] when an ON signal is output (excitation: active ON)" or an "open circuit between terminals [Y5A] and [Y5C] when an ON signal is output (non-excitation: active OFF)".
Contact output	[30A]	Integrated alarm output	(1) When the inverter stops with an alarm, an integrated alarm is output at the relay contact (1C). Contact capacity: 250 VAC 0.3 A cosp = 0.3, 48 VDC 0.5 A (2) The same signals as those of terminals [Y1] to [Y4] can be selected and output. (3) It is possible to switch between a "short circuit between terminals [30A] and [30C] when an ON signal is output (excitation: active ON)" or an "open circuit between terminals [30A] and [30C] when an ON signal is output (non-excitation: active OFF)".
	[30C]	Integrated alarm output	(1) When the inverter stops with an alarm, an integrated alarm is output at the relay contact (1C). Contact capacity: 250 VAC 0.3 A cosp = 0.3, 48 VDC 0.5 A (2) The same signals as those of terminals [Y1] to [Y4] can be selected and output. (3) It is possible to switch between a "short circuit between terminals [30A] and [30C] when an ON signal is output (excitation: active ON)" or an "open circuit between terminals [30A] and [30C] when an ON signal is output (non-excitation: active OFF)".
Communication	[DX+]	Via RS-485 communication link port 2	This is an input / output terminal used to connect a computer or programmable controller, etc. by RS-485 communication. (Refer to the User's Manual, Chapter 2, "2.2.7 Switching switches" for details on terminating resistance). When a multi-stop connection, use the recommended rod terminal. (Refer to "Table 2-7 Recommended rod terminals" in section "2.2.5 Screw Specifications and Recommended Wire Size" (Control Circuit Terminals) for details on recommended rod terminals).
	[RJ-45]	RS-485 communication port 1 (for keypad connection)	(1) This is used as a connector for connecting the keypad. The keypad power is supplied from the inverter via an extension cable for remote operation. If using an extension cable, turn ON the SW3 terminating resistor. This is used to connect a computer or programmable controller, etc. by RS-485 communication after disconnecting the keypad. (Refer to the User's Manual, Chapter 2, "2.2.7 Switching switches" for details on terminating resistance). * Pins 1, 2, 7, and 8 are assigned as the power supply source for the keypad. When connecting this RJ-45 connector to other devices, do not use these pins. Do not connect the PLC LAN network, Ethernet hubs, or telephone lines to the RJ-45 connector. The inverter and the connected device may be damaged. <b>Failure to observe this could result in fire.</b>
Communication	USB connector	USB port (keypad)	This is a USB connector (miniB specification) for connecting to a computer. Function codes can be edited, transferred, and verified, an inverter test run can be performed, and all states can be monitored using the inverter support loader (FRENC Loader). * Refer to the User's Manual, Chapter 9 "9.2 FRENC Loader Overview" for details.

### Chapter 3 OPERATION USING THE KEYPAD

Refer to the User's Manual, Chapter 3 "OPERATION USING THE KEYPAD" for details.

#### 3.1 Names and Functions of Keypad Components

The keypad allows you to run and stop the inverter, display various data, configure function code data, monitor I/O signal states, and display maintenance information and alarm information.

If using the multi-function keypad (TP-A25W), refer to the instruction manual for the multi-function keypad.



Item	Display and keys	Function overview
LED monitor	Five-digit, 7-segment LED monitor	Displays the following content based on the operation mode. <ul style="list-style-type: none"> <li>In Running mode: Running status information (e.g., output frequency, current, and voltage)</li> <li>Changes to the status display when not in the normal running status. Changes to the light alarm display when a light alarm occurs.</li> </ul>
	Program / Reset key	<ul style="list-style-type: none"> <li>In Programming mode: Menus, function codes and their data</li> <li>In Alarm mode: Alarm code, which identifies the alarm factor that has activated the protective function.</li> </ul>
Operation keys	Function / Data key which switches the operations you want to do in each mode as follows.	<ul style="list-style-type: none"> <li>In Running mode: Pressing this key switches the information to be displayed concerning the status of the inverter (output frequency (Hz), output current (A), output voltage (V), etc.)</li> <li>In Programming mode: Pressing this key displays the function code or establishes data.</li> <li>In Alarm mode: Pressing this key displays the details of the problem indicated by the alarm code that has come up on the LED monitor.</li> </ul>
	Program / Reset key	Press to run the motor (when performing keypad operation).
LED indicators	LED indicator (green)	Press to stop the motor (when performing keypad operation).
	LED indicator (green)	Press these keys to select the setting items and change the function code data displayed on the LED monitor.
USB port	USB port	<ul style="list-style-type: none"> <li>In Running mode: Functions assigned with function code E70 can be used. Hold down (for 1 second) to turn the function ON and OFF. The function is always OFF when the power is turned ON. Refer to the User's Manual, "3.3.8 Switches between local and remote modes" for details.</li> <li>In Programming mode: Jumps to the next menu number.</li> <li>While function code displayed: Jumps to the displayed number +10.</li> <li>While setting numerical values: Moves the cursor digit to the right.</li> <li>In Alarm mode: The alarm detailed information number shifts +10.</li> </ul>
	LED indicators	Lights when running with a run command entered by the $\overline{C}$ key, by terminal command "FWD" or "REV", or through the communications link. In Programming and Alarm modes, however, pressing this key can turn the inverter even if this indicator lights. The LED blinks every second while in local mode.
Unit LEDs (3 red LEDs)	Hz, A, kW, min, min	Indicates the signal selected with function code E71. Refer to the User's Manual, Chapter 5 "5.3.2 Codes (terminal functions)" for details.
	Unit LEDs (3 red LEDs)	These three LED indicators identify the unit number displayed on the LED monitor in Running mode by combination of it and unit status of them. Refer to the User's Manual, "3.3.1 Operating Status Monitor" for details. PRG. MODE: While the inverter is in Programming mode, the 2 LEDs on the left and right light up. (● Hz ○ A ● kW)

### 3.2 Destination Setting

For inverter type FRN\*\*\*G2□□-G (Global Model), the destination must be set first after the initial power supply. Without setting the destination, the function code cannot be changed. The inverter cannot be operated either. By setting the destination, basic function codes such as rated voltage, rated frequency, etc. are initialized to general values in each region (Table 3-2). If the destination value setting is changed after the initial destination setting, it can be changed with  $\overline{B}$   $\overline{D}$   $\overline{E}$   $\overline{S}$  in the program mode menu or function code H  $\overline{I}$   $\overline{D}$ . If the destination is reset by  $\overline{B}$   $\overline{D}$   $\overline{E}$   $\overline{S}$ , all function codes are initialized to the factory defaults. If the destination is set by H  $\overline{I}$   $\overline{D}$ , only the function codes in Table 3-2 are initialized to the values in Table 3-2. The destination can be changed after the initial destination setting. It can be changed with  $\overline{B}$   $\overline{D}$   $\overline{E}$   $\overline{S}$  in the program mode menu. If the function code set including the destination setting function code (H  $\overline{I}$   $\overline{D}$ ) is copied with the data copy function or the FRENC Loader, manual destination setting is not required. Set the initial destination as shown below.

(1)  $\overline{B}$   $\overline{D}$   $\overline{E}$   $\overline{S}$  appears when turning ON the power for the first time. If this appears, press the  $\overline{C}$  key.  
(2)  $\overline{B}$   $\overline{D}$   $\overline{E}$   $\overline{S}$  (Asian region) is displayed first. For other regions, Press  $\overline{C}$  key or  $\overline{C}$  key to select the destination.  
(3) After selecting the destination,  $\overline{S}$   $\overline{R}$   $\overline{I}$   $\overline{E}$  is displayed by pressing  $\overline{C}$  key and the destination setting is completed. Then,  $\overline{D}$   $\overline{I}$   $\overline{D}$  is displayed.

Note: If the inverter is not equipped with a keypad, please purchase either TP-E2 or TP-A25W before carrying out the above procedure. (The above description is based on the use of TP-E2.)

Destination	Asia	China	Europe	Americas	East Asia	Japan
LED display	B $\overline{D}$ $\overline{E}$ $\overline{S}$	C $\overline{H}$	E $\overline{U}$	R $\overline{I}$ $\overline{E}$ $\overline{F}$	E $\overline{S}$ $\overline{E}$ $\overline{B}$	J $\overline{P}$ $\overline{N}$
H $\overline{I}$ $\overline{D}$ Destination	2	3	4	5	6	1
F02: Operation method	2	2	2	0	2	2
F03A101601101: Maximum output frequency 1 to 4	60 Hz (200V)	50 Hz (200V)	50 Hz	60 Hz	60 Hz	60 Hz
F04A0230202: Base frequency 1 to 4	50 Hz (400V)	50 Hz (400V)	50 Hz	60 Hz	60 Hz	50 Hz
F05A0302303: Rated voltage at base frequency 1 to 4	220/240V	380V	400V	230/460V	200/400V	200/400V
F06A04040404: Torque boost 1 to 4	HP rating motors	Fuji IE3 motor Standard value	HP rating motors	Fuji IE3 motor Standard value	HP rating motors	Fuji IE3 motor Standard value
F09A05050505: Torque boost 1 to 4	HP rating motors	Fuji IE3 motor Standard value	HP rating motors	Fuji IE3 motor Standard value	HP rating motors	Fuji IE3 motor Standard value
F11A07070707: Electronic thermal 1 to 4 (Overload detection level)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
F14: Restart mode after momentary power failure (Mode selection)	HND	1	0	0	1	1
FB: Switching between HND and HHD drive modes	HND	HND	HND	HND	HND	HND
E31/E36/E54: Frequency detection 1 to 3 (Level)	60 Hz (200V)	50 Hz (200V)	50 Hz	60 Hz	60 Hz	60 Hz
E34/E37/E55: Overload early warning / Current detection 1 to 3 (Level)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
P02A16161616: Motor 1 to 4 (Rated capacity)	kW	kW	kW	HP	kW	kW
P03A1701717171: Motor 1 to 4 (Rated current)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
P06A20020020: Motor 1 to 4 (No-load current)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
P07A21021021: Motor 1 to 4 (%R1)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
P08A22022022: Motor 1 to 4 (%X)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
P12A26026026: Motor 1 to 4 (Rated slip frequency)	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value	Fuji IE3 motor Standard value
P21A35035035: Motor 1 to 4 (Torque current under vector control)	5	5	5	1	5	5
P99A39039039: Motor 1 to 4 selection	0	0	0	3	0	0
H66: STOP key priority / Start check function	0	0	0	3	0	0
K01: Multifunction keypad TP-A25W (Language selection)	1	6	1	1	1	0

### Chapter 4 FUNCTION CODES

The PDF manual can be downloaded from below QR code. For more information of Function codes list.



https://www.fujielectric.com/products/inverter/frency-megag2/download\_pr1

### Function codes (excerpt)

Function code	Name	Data setting range
F01	Frequency setting 1	0: Keypad key operation ( $\overline{C}$ / $\overline{C}$ keys)
		1: Analog voltage input (Terminal [I2]) (from 0 to ±10 VDC)
		2: Analog current input (Terminal [I1]) (4 to 20 mA DC)
		3: Analog voltage input (Terminal [I2]) + analog current input (Terminal [I1])
		4: Analog voltage input (Terminal [I2]) (from 0 to ±10 VDC)
		5: Analog voltage input (Terminal [I3]) (from 0 to ±10 VDC)
		6: Analog voltage input (Terminal [I3]) (from 0 to ±10 VDC)
		7: UP/DOWN control
		8: Keypad key operation ( $\overline{C}$ / $\overline{C}$ keys) (with balanceless bumps)
		9: Pattern operation
10: Digital input interface card OPC-D (option)		
11: Pulse train input		
F02	Operation method	0: Keypad operation (Rotation direction input; terminal block)
		1: External signal (digital input)
		2: Keypad operation (forward rotation)
F03	Maximum output frequency 1	0: AVR disable (output voltage proportional to power voltage)
		1: AVR enable (output voltage proportional to power voltage)
F04	Base frequency 1	0: 0 to 500V / AVR operation (400 V series)
		1: 0 to 500V / AVR operation (200V series)
F05	Rated voltage at base frequency 1	0: 0 to 240V / AVR operation (200V series)
		1: 160 to 500V / AVR operation (400 V series)
F06	Maximum output voltage 1	0: 0 to 240V / AVR operation (200V series)
		1: 160 to 500V / AVR operation (400 V series)
F07	Acceleration time 1	0: 0.0 to 6000ms
		1: 0.0 to 6000ms
F08	Deceleration time 1	0: 0.0 to 6000ms
		1: 0.0 to 6000ms
F09	Torque boost 1	0: 0.0 to 20.0% (% value against base frequency voltage 1)
		1: 0.0 to 20.0% (% value against base frequency voltage 1)
F10	Electronic thermal overload protection for motor 1 (Select motor characteristics)	0: 0.0 (disable), current value of 1 to 135% of inverter rated current set with a unit (inverter rated current dependent on F80)
		1: Enable (For a general-purpose motor with self-cooling fan)
F11	(Operation level)	0: 0.0 (disable), current value of 1 to 135% of inverter rated current set with a unit (inverter rated current dependent on F80)
		1: Enable (For an inverter-driven motor with separately powered cooling fan)
F14	Restart mode after momentary power failure (operation selection)	0: Trip immediately
		1: Trip after a recovery from power failure
F16	Frequency limiter (Lower limit)	0: 0.0 to 599.9 Hz
		1: 0.0 to 599.9 Hz
F20	Motor sound (Carrier frequency)	HND specification
		HND specification
P02	Motor 1 (Rated capacity)	FRN***G2S-2G FRN***G2□-4G FRN***G2S-2G FRN***G2□-4G
		0.75 to 16kW: 0005 to 0288 0002 to 0150 0032 to 0075 0016 to 0038
P03	Motor 1 (Rated current)	0.75 to 16kW: 0346 to 0432 0180 to 1386 0092 to 0215 0045 to 0150
		0.75 to 16kW: — — 0288 to 0432 0180 to 1386
P04	Motor 1 selection	0: 0.0 to 2000 A
		0: Disable
P99	Motor 1 selection	1: Stop tuning
		2: Rotation tuning
P99	Motor 1 selection	3: Synchronous motor magnetic pole position offset tuning
		5: Stop tuning (%R1, %X only)
P99	Motor 1 selection	0: Motor characteristics 0 (Fuji standard IM, 8-series)
		1: Motor characteristics 1 (HF rating IM)
P99	Motor 1 selection	2: Motor characteristics 2 (Fuji dedicated motors for vector control)
		3: Motor characteristics 3 (Refer to replacement material using Fuji standard IM, 6-series)
P99	Motor 1 selection	4: Other IMs
		5: Motor characteristics 5 (Fuji premium efficiency motors)
P99	Motor 1 selection	20: Other (synchronous motors)
		21: Motor characteristics (Fuji synchronous motor (N82 series))
P99	Motor 1 selection	22: Motor characteristics (Fuji synchronous motor (GN2 series))
		23: Motor characteristics (Fuji synchronous motor (GN1 series))

### Chapter 6 MAINTENANCE AND INSPECTION

#### 6.1 Inquiries about Product and Guarantee

##### 6.1.1 When Making an Inquiry

Upon break